

Breadman[®]

Bring Home the Bakery[™]



INSTRUCTION MANUAL

BREADMAN[®] BREAD MAKER

RECIPES INCLUDED
see reverse side

www.breadman.com

- BK2000B
- BK2000BQ

Please Read and Save this Use and Care Book

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact Consumer Services for examination, repair or electrical or mechanical adjustment. Or, call the appropriate toll-free number on the cover of this manual.
- The use of accessory attachments not recommended by the appliance manufacturer may cause fire, electric shock or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces, including the stove.
- Do not place on or near a hot gas or electric burner, or in a heated oven.

- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- To disconnect, press and hold the STOP button for several seconds, remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Avoid contacting moving parts.

SAVE THESE INSTRUCTIONS

This product is for household use only.

CustomerCareLine:

USA/Canada
1-800-231-9786

Accessories/Parts
(USA / Canada)
1-800-738-0245

For **online customer service**
and to **register** your product, go to
www.prodprotect.com/applica



Caution, hot surfaces: This appliance generates heat and escaping steam during use. Proper precautions must be taken to prevent the risk of burns, fires or other injury to persons or damage to property.

POLARIZED PLUG (120V Models Only)

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

TAMPER-RESISTANT SCREW

Warning: This appliance is equipped with a tamper-resistant screw to prevent removal of the outer cover. To reduce the risk of fire or electric shock, do not attempt to remove the outer cover. There are no user-serviceable parts inside. Repair should be done only by authorized service personnel.

ELECTRICAL CORD

- a) A short power-supply cord (or detachable power-supply cord) is to be provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
- b) Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use.
- c) If a long detachable power-supply cord or extension cord is used,
 - 1) The marked electrical rating of the detachable power-supply cord or extension cord should be at least as great as the electrical rating of the appliance,
 - 2) If the appliance is of the grounded type, the extension cord should be a grounding-type 3-wire cord, and
 - 3) The longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over.

Note: If the power supply cord is damaged, it should be replaced by qualified personnel; in Latin America, by an authorized service center.

POWER OUTAGE

7-Minute Power Failure Back-Up

Your Breadman® Bread Maker has a 7-minute power failure back-up feature. If the electricity goes out, the memory will store your cycle selection for up to 7 minutes. If the power comes back on within this time, bread making will resume where it left off.

If the bread maker loses power for more than 7 minutes and you are using any dairy products, perishables or meat in your bread, you should discard the contents of the recipe and start again with new fresh ingredients due to health and sanitary considerations. For nonperishable recipes you may try starting the bread maker at the beginning of the cycle again. However, this may not always produce an acceptable loaf of bread.

If you are not sure when the outage occurred, remove the dough and discard.

Product may vary slightly from what is illustrated.

- † 1. Removable lid (Part # BK2000BQ-01)
- 2. Lid handle
- 3. Cord wrap (not shown)
- 4. Viewing window
- 5. Automatic fruit & nut dispenser
- 6. Control panel
- 7. Baking chamber
- † 8. Traditional bread pan (Part # BK2000BQ-02)
- † 9. 1-lb. bread pans (2) (Part # BK2000BQ-03)
- † 10. Collapsible kneading paddles for traditional bread pan (2) (Part #BK2000BQ-04)
- † 11. Non-collapsible kneading paddles for 1-lb. bread pans (2) (Part #BK2000BQ-05)
- † 12. Measuring cup (Part #BK2000BQ-06)
- † 13. Measuring spoon (Part #BK2000BQ-07)
- † 14. Kneading paddle removal key (Part # (Part #BK2000BQ-08)

Note: † indicates consumer replaceable/removable parts



CONTROL PANEL



1. POWER LIGHT

Illuminates when **START** button is pressed.

2. DISPLAY WINDOW

Shows selection and timer setting.

3. MENU BUTTON

Selects cycle. Each time the **MENU** button is pressed, the number for the cycle selected and the program time will appear in the display window.

4. START/STOP BUTTON

Press and hold for several seconds to clear display, reset cycle or to simply stop baking.

5. ▲ AND ▼ BUTTONS

Use this pair of buttons to adjust the bake only time and to set delay bake timer; add or subtract time displayed in the display window.

- ▲ Increases in 10-minute intervals.
- ▼ Decreases time in 10-minute intervals.

6. LOAF BUTTON

Selects loaf size: 1½-lb., 2-lb. or 2½-lb.

Loaf size is preset to 2½-lb.

Rapid loaf is preset to 2-lb.

Note: For two, 1-lb. loaves, see section "BAKING ONE POUND LOAVES".

7. COLOR BUTTON

Selects crust color: light, medium or dark.

Crust color is preset to medium.

Note: When using Rapid bake, your crust color will be set to medium.

Note: When you press the buttons, you should hear a beep. This will let you know you've pressed hard enough to make your selection.

KNEADING AND BAKING CYCLES

Note: If at any time during bread making process you need to turn bread maker off, press and hold the **START/STOP** button for several seconds, then unplug the unit.

Note: If bread is not removed immediately after baking and **START/STOP** button is not pressed, a controlled 60-minute Keep Warm mode will begin (except during Quick Bread, Dough and Jam). For best results, remove bread immediately after baking process is complete.

WHITE

Used for breads that primarily include white bread flour, although some recipes may include small amounts of whole wheat flour.

WHOLE WHEAT

Used for recipes with significant amounts of whole wheat or rye flour, oats or bran. Whole wheat cycle begins with rest period during which flours or grains absorb liquid ingredients. Soaking causes flour or grain to soften and helps ingredients to combine. Generally, whole wheat and multi-grain breads are shorter and denser than white, French or sweet.

FRENCH

Traditionally, French bread has a slightly crispier crust and lighter texture than white bread. Recipes usually do not include butter, margarine or milk.

SWEET

Used for recipes that contain eggs, fruit juice, additional sugar or added sweet ingredients such as coconut flakes, raisins, dried fruit or chocolate. Baking temperature is reduced to prevent burning.

GLUTEN-FREE

Used for gluten-free recipes.

QUICK BREAD

Used for recipes that contain baking powder or baking soda, rather than yeast, to make bread rise. Cake recipes made from scratch must be specially designed for this cycle.

DOUGH

Use to prepare dough for making bread, rolls or pizza which are shaped and allowed to rise before baking in a conventional oven. This program blends and kneads the dough and takes it through the first rise.

LOW CARB

Used for recipes that are lower in carbohydrates.

JAM

Use to prepare preserves, marmalade, chutneys and ketchup. Add fruit, sugar and lemon juice for homemade preserves – a great topping for homemade bread, waffles and ice cream.

RAPID

Used for White, Whole Wheat and Sweet cycles to decrease time to approximately 1 hour. Choose recipe, then simply add ½ tsp. to amount of yeast listed for a 2-lb. loaf. Bread may be shorter and denser than bread made using the longer program.

BAKE ONLY

Used if crust is too light or you wish to bake pre-made dough – also especially useful if your bread is not quite done. Check every few minutes. Bakes for up to 1 hour, 30 minutes.

KNOW YOUR INGREDIENTS

FLOUR & OTHER GRAINS	
ALL-PURPOSE FLOUR	All-purpose flour is a blend of refined hard and soft wheat flours ideally suited for making quick breads and cakes.
BRAN	Bran (unprocessed) is coarse outer portion of wheat or rye grains that is separated from flour by sifting or bolting. It is often added to bread in small quantities for nutritional enrichment, heartiness and flavor. It is also used to enhance bread texture.
BREAD FLOUR	Bread flour typically has higher gluten concentration than all-purpose flour. Using bread flour will produce loaves with better volume and structure.
CORNMEAL AND OATMEAL	Cornmeal and oatmeal come from coarsely ground white or yellow corn and from rolled or steel-cut oats. They are used primarily to enhance flavor and texture of bread.
CRACKED WHEAT	Cracked wheat has very coarse texture. It comes from wheat kernels cut into angular fragments. It gives whole grain breads a nutty flavor and crunchy texture.
RYE FLOUR	Rye flour must always be mixed with high proportion of bread flour, as it does not contain enough gluten to develop structure for high, even-grained loaf.
SELF-RISING FLOUR	Self-Rising Flour is NOT RECOMMENDED for use with your bread maker. Self-rising flour contains leavening ingredients that will interfere with bread and quick bread making.
7 GRAIN CEREAL BLEND	7 grain cereal blend is a blend of cracked wheat, oats, bran, rye, cornmeal, flax seeds and hulled millet. It is used primarily to enhance flavor and texture of bread.
VITAL WHEAT GLUTEN	Vital Wheat Gluten is manufactured from wheat flour that has been treated to remove nearly all of the starch to leave a very high protein content. (Gluten is the protein in wheat that makes dough elastic.) Vital Wheat Gluten is available at most health food stores. It can be used in small portions to increase volume and lighten texture.
WHOLE WHEAT FLOUR	Whole wheat flour is milled from the entire wheat kernel, which contains the bran and germ. This high fiber flour is richer in nutrients than all-purpose or bread flour. Breads made with this flour are usually smaller and heavier than white loaves. Many recipes mix whole wheat flour with bread flour or vital wheat gluten to produce higher, lighter-textured bread.

TIPS ON FLOUR STORAGE

Keep flour in a secure, airtight container. Store rye and whole wheat flours in a refrigerator, freeze or a cool area to prevent them from becoming rancid. Allow flour to come to room temperature before using.

Note: Flours, while visibly similar, can be very different in how they are ground, milled, stored, etc. You may have to experiment with different brands of flour to help you make the perfect loaf. See **RECIPE TIPS** to assist with these experiments.

YEAST

Active yeast, through a fermentation process, produces carbon dioxide gas necessary to make bread rise. Yeast feeds on carbohydrates in sugar and flour to produce this gas. Three different types of yeast are available: fresh (cake), active dry and quick-acting. Quick, rapid rise and bread machine yeasts are quick-acting. Fresh (cake) yeast is NOT RECOMMENDED for use with your bread maker.

TIPS ON YEAST

Ensure your yeast is fresh by checking its expiration date. Ideally, yeast should be used several months before the expiration date. Once a package or jar of yeast is opened, it is important that the remaining contents be immediately resealed and refrigerated or frozen for future use. Often dough that fails to rise is due to stale yeast.

Note: Basic bread and dough recipes in this booklet were developed using active dry yeast. You may use chart below to substitute any quick-acting yeast (quick rise, fast rise or bread maker yeast) for active dry yeast.

CONVERSION CHART FOR BREAD MACHINE YEAST

$\frac{3}{4}$ tsp. bread machine yeast = $\frac{1}{2}$ tsp. quick-acting yeast
1 tsp. bread machine yeast = $\frac{3}{4}$ tsp. quick-acting yeast
 $1\frac{1}{2}$ tsp. bread machine yeast = 1 tsp. quick-acting yeast
 $2\frac{1}{4}$ tsp. bread machine yeast = $1\frac{1}{2}$ tsp. quick-acting yeast
1 tbsp. bread machine yeast = 2 tsp. quick-acting yeast

RAPID CYCLES

Rapid cycle settings for White, Whole Wheat and Sweet decrease time for making your favorite bread in approximately 1 hour. Choose recipe, then add an additional $\frac{1}{2}$ tsp. of bread machine yeast to the recipe. The bread may be shorter and denser.

ADDITIONAL INGREDIENT NOTES	
Important: Exact measurements for ingredients are the most important part of baking. It is the key to getting great texture and consistency in your bread. <u>Make sure to measure all ingredients exactly.</u>	
BAKING POWDER	Double-acting baking powder is a leavening agent used in quick breads and cakes. This type of leavening agent does not require rising time before baking, as chemical reaction works when liquid ingredients are added and again during baking process.
BAKING SODA	Baking soda is another leavening agent, not to be confused or substituted for baking powder. It also does not require rising time before baking, as chemical reaction works during baking process.
EGGS	Eggs add richness and velvety texture to bread dough and cakes. When recipe calls for egg(s), large egg(s) at room temperature should be used.
FATS	Butter, margarine and oil shorten or tenderize the texture of yeast breads. French bread gets unique crust and texture from the lack of added fat. However, breads that call for fat stay fresh longer. If butter is used directly from refrigerator, it should be cut into small pieces for easier blending during kneading process.
LIQUIDS	All liquids should be warm 80°F/27°C to 90°F/32°C for all recipes. Liquids, such as milk, water or a combination of powdered milk and water, can be used when making bread. Milk will improve flavor, provide velvety texture and soften the crust, while water alone will produce a crispier crust. Vegetable or fruit juices and potato water may be used for flavor variety.
SALT	Salt is necessary to balance flavor in breads and cakes; it also limits growth of yeast. Changing the amount of salt in a given recipe may result in shorter, gummier bread. When first making a type of bread, do not increase or decrease amount of salt shown in the recipe.
SUGAR	Sugar is important for color and flavor of breads. It also serves as food for yeast since it supports the fermentation process. Recipes in this book that call for sugar require granulated sugar. Important: Do not substitute powdered sugar. Artificial sweeteners cannot be used as substitute, as yeast will not react properly with them.

CLIMATE CHANGES & BAKING

- In high-altitude areas (over 3,000 feet) dough tends to rise faster, as there is less air pressure. Therefore, less yeast is necessary.
- In dry climates, flour is drier and requires slightly more liquid.
- In humid climates, flour is wetter and will absorb less liquid, so less liquid is required.

HOW TO USE

THIS PRODUCT IS FOR HOUSEHOLD USE ONLY.

GETTING STARTED

- Remove packing materials and any stickers.
- Please go to www.prodprotect.com/applica to register your warranty.
- Place bread maker on dry, stable, level surface away from heat and areas where cooking grease or water may splatter on unit. Do not place near edge of countertop. If placing beneath cabinets, make sure there is enough room to open the lid without interference.

Important: Your bread maker will bake up at 2½-lb. loaf.

Do not put larger quantities of ingredients into bread pan. Bread will not mix and bake correctly and bread maker may be damaged. (See MAXIMUM INGREDIENT AMOUNTS.)

- Before first use, operate on Rapid White cycle without adding ingredients to burn off manufacturing oils. (Follow instructions in USING YOUR BREAD MAKER.)
Note: During first use, bread maker may smoke and/or emit an odor from mineral oils used in manufacturing. This is normal.

MAXIMUM INGREDIENT AMOUNTS

- Bread cycles: approximately 5 cups
- Quick breads: 4 cups
- Dough cycle: 4 ⅔ cups
- Jam: 3 cups of fruit mixture

BREAD PAN TIPS

Inserting bread pan

Note: Remember to insert kneading paddles first, then add all ingredients in the order listed BEFORE inserting the bread pan into baking chamber.

Important: Collapsible kneading paddles may fall when ingredients are added. This is normal. They will stand up when kneading begins.

- When inserting bread pan into bread maker, make sure to set firmly in place.

Removing bread pan

- To remove bread pan from baking chamber, hold handle with an oven mitt and lift straight up.

Important: When you remove bread pan after baking, be sure to wear oven mitts to prevent burning.

- After removing loaf (by turning bread pan upside down and shaking gently), check to see that kneading paddle is removed from loaf. If it is stuck in bread, allow bread to cool; then use the paddle removal key to remove it, taking care not to scratch the kneading paddles. Allow bread to cool before removing the kneading paddles.

CHECKING DOUGH CONSISTENCY

Although your bread maker will mix, knead and bake bread automatically, when baking bread from scratch, it is recommended that you learn to recognize condition of your dough. The ratio of flour to liquid is the most critical factor in any bread recipe, yet the most easily remedied. After 5 to 8 minutes in Knead 2, open bread maker to check consistency of dough. Dough should be in a soft, tacky ball (feel sticky like scotch tape). If it is too dry, add 1 tsp. of liquid at a time. If it is too wet, add 1 tbsp. of flour at a time.

USING YOUR BREAD MAKER

Note: Depending on the cycle or recipe used, some steps may not apply or there may be additional steps. Refer to the respective recipes instructions in the recipes portion of this book, as well as the specific cycle instructions located at the end of these usage instructions.

1. Open lid and remove bread pan. Lift bread pan straight up and out using the handle **(B)**.



Caution: Do not turn or shake bread pan while taking it out. If the bread pan is bent, temperature sensor may not work properly.

2. Position kneading paddle on the drive shaft. Match flat side of drive shaft to flat part of hole in kneading paddle **(C)**. Make sure paddle is secure.




Note: As you add ingredients into the bread pan, the collapsible kneading paddles may fall; this is normal. Paddles will stand up automatically once the cycle is started.

Important: Add ingredients to bread pan in the order listed in the recipe.

Important: Always add yeast last.

4. Make small indentation on top of dry ingredients (not so deep it reaches the wet layer) and add yeast **(D)**.

Important: Indentation for yeast is important, especially when using the delay bake timer. It keeps yeast away from the wet ingredients until the kneading process begins. (Liquid ingredients will prematurely activate the yeast.)



5. Insert the bread pan into the baking chamber **(E)**. Press down on rim of bread pan until it snaps securely into place.



6. Close the lid. If your recipe includes extra ingredients such as fruits or nuts (listed after the yeast in the recipe), add these to the automatic fruit and dispenser.

Important: Do not exceed 2/3 cup capacity.

Important: Do not pour liquids or spices into dispenser. Always make sure fresh fruit or vegetables are not wet; pat dry before putting them in the dispenser.

7. Plug into standard electrical outlet. Bread maker will beep and program 1 and 3:25 will appear in the display window.

8. Press **MENU** to choose desired cycle **(F1)**. The **POWER** light will illuminate. Each time **MENU** is pressed, unit and display will move to the next cycle.

Note: As the **MENU** button is pressed, the Rapid cycle setting will follow the regular cycle setting for White, Whole Wheat and Sweet.

9. Press **CRUST** to choose crust color **(F2)**. Bread maker is preset for medium crust.

Note: CRUST will not be activated for the following cycles:

- Jam
- Dough
- Bake Only
- Rapid



10. Press **LOAF** to select loaf size **(F3)**. Bread maker is preset to 2½ lb.

Note: Loaf size cannot be activated for the following cycles:


- Jam
- Dough
- Rapid
- Gluten Free
- Low Carb

11. Press **START** to begin kneading cycle **(F4)**. The **POWER** light will illuminate. The time remaining will begin to count down in display window. Bread making time, program number and color will be shown in display window.

Note: During kneading cycle, yeast will activate and viewing window may begin to fog. (This will clear eventually so you can view the progress.)

12. When your bread is finished baking, bread maker will beep and "3:25" will appear in display window. Press **START/ STOP** and open lid. Using oven mitts, remove bread pan **(G)**.

Important: Remember, bread pan and loaf are both very hot! Be careful not to place either on tablecloth, plastic surface or other heat-sensitive surface that may scorch or melt.



Note: If bread is not removed immediately after baking and **START/ STOP** is not pressed, the Keep Warm mode will begin. Bread maker will automatically turn off after 60 minutes. For best results, remove bread immediately after baking.

Note: Keep Warm does not apply to the following cycles:

- Jam
- Dough
- Bake Only

13. Turn bread pan upside down and shake to release bread (**H**). Place bread upright on wire rack to cool at least 20 minutes before slicing.

Note: The collapsible kneading paddles are designed to stay in the bread pan instead of sticking in your bread. Check to see if the paddles stayed in the pan. If not, follow the caution statements below when removing.

Caution: Be sure to remove kneading paddle from the bread before serving.

Caution: Bread pan, kneading paddle and bread will be very hot. Allow bread to cool before removing the paddle and always use the paddle removal key.

14. Unplug unit and allow to cool completely before cleaning. (See CARE AND CLEANING INSTRUCTIONS.)



Important: Make sure to clean the inside of the baking chamber thoroughly after each use.

15. Once bread has cooled (approximately 2 hours) store in an airtight container.

BAKING ONE POUND LOAVES

Important: You can bake either one or two breads at a time, as desired. The recipe book contains recipes for White, Whole Wheat, French, Sweet, Low Carb and Gluten Free 1-lb. loaves (see 1-lb. loaves recipe section at the back of the recipe book).

1. Open lid and remove traditional bread pan (if stored in appliance.)

Caution: Do not turn or shake bread pan while taking it out. If the bread pan is bent, temperature sensor may not work properly.

2. Insert one of the two non-collapsible kneading paddles (do not use collapsible paddles) into each of the 1-lb. bread pans. Position kneading paddle on the drive shaft. Match flat side of drive shaft to flat part of hole in kneading paddle. Make sure paddle is secure.
3. Follow steps 3 and 4 in USING YOUR BREAD MAKER to add ingredients.
4. Insert one bread pan over each drive coupling in the baking chamber and press down on rim of bread pan until it snaps securely in place.
5. Follow steps 5 through 9 in USING YOUR BREAD MAKER to begin setting programming.

6. For LOAF size, press the ▲ and ▼ buttons simultaneously and hold; unit will beep and display will indicate loaf size of (2) 1.0 lbs.
7. Press **START** to begin kneading cycle. The **POWER** light will illuminate. The time remaining will begin to count down in display window. Bread time and loaf size will be shown in display window.
8. If additional ingredients are listed after the yeast, such as nuts and fruits, listen for the beep near the end of the kneading cycle, about 30 minutes into the program. Add those ingredients.

Important: Do not use the automatic fruit and nut dispenser with the 1-lb. bread pans.

9. Follow directions from step 12 to 15 in USING YOUR BREAD MAKER to finish baking.

SLICING AND STORING BREAD

For best results, place bread on wire rack and allow to cool at least 20 minutes before slicing. Use electric knife or serrated knife for even slices.

Store unused bread, tightly sealed (sealable plastic bags or plastic containers work well) at room temperature for up to 3 days. For longer storage, (up to 1 month) place bread in sealed container in freezer. Since homemade bread has no preservatives, it tends to dry out and become stale faster. Leftover or slightly hardened bread may be cut into ½-inch or 1-inch cubes and used in recipes to make croutons, bread pudding or stuffing.

USING 15-HOUR DELAY BAKE TIMER

Important: Delay baking does not activate JAM cycle. Do not use delay bake timer if your recipe includes perishables, such as, eggs, fresh milk, yogurt or other dairy products and meats, etc.

To preset your bread maker, follow these steps:

1. Add ingredients in the order listed as usual, taking care not to let yeast and liquid ingredients contact one another.

Note: If your recipe contains salt, add it with the liquid ingredients, taking care to keep it away from the yeast.

2. Close bread maker lid and plug it in.
3. Press **MENU** to choose cycle. Time needed for selected cycle appears in display window.
4. Press ▲ to add time in 10-minute intervals. (Use ▼ to subtract time.) Amount of time set is shown in display window.

- To fast-forward time, continually press ▲ .
- To fast-reverse, continually press ▼ .
- For example, if it is 8:00 AM and you want bread ready at 1:00 PM, press ▲ until the display reads 5:00 – meaning it will finish baking in 5 hours. This is the hour difference between 8:00 AM and 1:00 PM.

Note: Actual baking times will not change.

- Press **LOAF** to choose loaf size, press **CRUST** to choose crust color, then press **START** to begin timer. The colon (:) in time display begins to flash, letting you know timer is started. When your bread is finished baking, bread maker will beep and "0:00" will appear in display window. Press **START/STOP** and open lid.
- If you make an error after you've activated program and want to start over, press and hold **START/STOP** for approximately 5 seconds. Timer will clear and you can begin again.

BAKE ONLY

The Bake Only cycle offers the flexibility to vary time. You can bake pre-made dough or dough purchased at the store using this cycle. You may also use this cycle if crust color is too light or if your sweet bread is not quite done. Check every few minutes.

- Press the **MENU** button and move to cycle 13.
- Adjust the amount of time you need up to 90 minutes.
- Press **START** to begin baking.

SPECIAL GLAZES FOR YEAST BREADS

Select one of the following special glazes to enhance your bread.

- Melted Butter Crust: Brush melted butter over just-baked bread for a softer, more tender crust.
- Milk Glaze: For a softer, shiny crust, brush just-baked bread with milk or cream.

- Sweet Icing Glaze: Mix 1 cup sifted confectioner's sugar with 1 to 2 tablespoons of milk, water or fruit juice until smooth. Drizzle glaze over raisin or sweet bread when they are almost cool.

Note: If desired, generously sprinkle with your choice of nuts or seeds after glazing.

DOUGH CYCLE

Tips for Best Results

- If using delay bake timer, make sure yeast is on top of flour, away from liquids.

Important: Never allow dough to remain in bread maker after cycle is complete; it may over rise and damage machine.

- Rising times for dough after it is shaped and placed in baking pan will vary due to recipe, temperature and humidity level of your kitchen. Optimum temperature for rising is 80°–85°F. Rising is the most essential feature in bread making.
- Bread maker allows dough to have first rise or fermentation before dough is removed. Fermentation conditions gluten, (becoming pliable and elastic with a soft, smooth quality) develops flavor and leavens product.
- Sometimes a double rising is beneficial especially for whole grain or 100% whole wheat bread. Let dough rise once in bread maker. Remove from bread maker, punch down, let rise again, punch down and let rest 10 minutes. Resting allows gluten to relax and makes handling easier. Shape as

desired and allow to rise until doubled in volume. If only 1 rise is desired, remove from bread maker, let rest, shape and rise as above.

- Baker's Tip: Dough has doubled in volume when an indentation remains after tip of a finger is pressed lightly and quickly into dough. If indentation springs back, cover and let rise a few more minutes and check again.

SPECIAL TIPS FOR MAKING DOUGH

Important: For use only with the Dough Cycle

- Always allow optimum rising of shaped dough.
- Use pastry brush to apply glaze.
- Bake as directed in recipe.

APPLY JUST BEFORE BAKING

Egg Yolk Glaze

For shiny golden crust, mix 1 slightly beaten egg or egg yolk with 1 tbsp. water or milk.

Egg White Glaze

For shiny, chewy crust, mix 1 slightly beaten egg white with 1 tbsp. water.

If desired, sprinkle chopped nuts or fruit and/or seeds after glazing.

Lightly Floured

Sprinkle enough flour onto work area so dough can be handled without sticking.

SHAPED ROLLS

Important: Once rolls are shaped, cover and let rise until doubled before baking.

Cloverleaf Rolls

Shape into ½-inch balls. Place 3 balls in each greased muffin tin.

Crisscross Rolls

Shape into balls, setting 2 aside. Combine balls and roll into a ⅛-inch thick square. Cut strips ⅛-inch wide and 2-inches long. Brush top of roll with beaten egg. Place 1 strip across top of each ball. Repeat process, placing second strip in opposite direction across top of each ball.

Traditional Rolls

Shape into balls. For "pull apart" rolls, place dough balls with sides touching in 8 or 9-inch round or square greased baking pan. For "individual" rolls place dough balls 2 inches apart.

Crescent Rolls

On lightly floured board, roll dough to 12-inch circle. Spread with softened butter. Cut into 16 wedges beginning at wider end. Place rolls 2-inches apart on greased baking sheet with points underneath; curve rolls slightly. If desired, brush with melted butter just before baking.

Rosettes

On lightly floured board, roll about 1½ oz. piece of dough into 14-inch rope. Tie in a loose knot, leaving 2 long ends. Tuck one end under knot and second end into the top center of the loose knot. Place 2-inches apart on lightly greased baking sheet.

JAM CYCLE

Method:

1. Following steps in USING YOUR BREAD MAKER; select **JAM** cycle.
2. Once **JAM** cycle is complete, remove bread pan from bread maker and pour hot mixture into heat-safe jars, leaving ½” of space at the top.
3. Allow to partially cool. Cover tightly to store. Mixture will thicken upon cooling.

Tips for Best Results

- Do not reduce sugar or use sugar substitutes. Exact amounts of sugar, fruit, and other ingredients are necessary for good set.
- Use only ripe fruit (not overripe or under-ripe) for best flavor.
- Do not puree fruit. Jam should have bits of fruit in it.
- Recipes should not exceed 3 cups fruit.
- Remove stems, seeds or pits from fruit.
- You may use strawberries, blackberries, raspberries or other thin skinned berries. Fruit such as peaches, pears and apricots may be used, but should be peeled and have seeds removed.
- Frozen berries or fruit (no sugar added) may be substituted for fresh. Thaw and drain before measuring. For thinner jam, use juice as part of 3 cups of berry or fruit amount.
- Lemon juice adds necessary acid to berries or fruit.
- You may decrease amount of sugar, but it will produce a thinner result. More sugar will make it thicker. For best results, sugar substitutes are not recommended.
- Average refrigerated life of jam is 2 weeks or up to several months if frozen.

Important: Do not exceed amounts given in recipes!

Care and Cleaning

This product contains no user serviceable parts. Refer service to qualified service personnel.

CLEANING

Important: Always unplug bread maker and allow to cool completely prior to cleaning.

Bread pan and kneading paddle have nonstick surfaces, which make cleaning easier.

1. After baking each loaf of bread, unplug bread maker and allow to cool; discard any crumbs.
2. Remove bread pan from oven chamber and kneading paddle from bread pan. Wash bread pan and kneading paddle inside and out with warm, soapy water. Avoid scratching nonstick surfaces.

Caution: Do not place bread pan in dishwasher, or soak it in water.

3. If kneading paddle is stuck to drive shaft, pour warm water into bread pan for up to 30 minutes, to loosen it. Do not use excessive force.

4. Wipe inside of lid and oven baking chamber with slightly damp cloth or sponge. If any residue has scorched on heating element or elsewhere, wipe with nonabrasive pad to clean. Lid can be removed for cleaning. Dry baking chamber and lid thoroughly.

Important: Do not put lid in dishwasher, as it may cause warping. Do not immerse in water, as it contains sensitive electronic sensors.

5. To clean glass in lid, use glass cleaner or mild detergent and damp cloth or plastic scouring pad. Do not use abrasive cleaners or scouring pads, as they may scratch glass.
6. Do not use vinegar, bleach or harsh chemicals to clean bread maker.
7. Be sure bread maker is completely cooled before storing.
8. Baking chamber contains heating element and drive shaft. When cleaning, NEVER pour water, solvents or cleaning solutions into this area.

STORAGE

All removable parts should be thoroughly cleaned and dried. Store lid closed. Place bread pan into bread maker with kneading paddle inside.

TROUBLESHOOTING

QUESTION	ANSWER
Why does height and shape of bread differ in each loaf?	Height and shape of bread may differ depending on the ingredients, room temperature and length of timer cycle. Also, accurate measurement of ingredients is essential to make delicious bread.
Bread has unusual aroma. Why?	Stale ingredients may have been used or too much yeast may have been used. Always use fresh ingredients. Accurate measurements are essential to make delicious bread.
Kneading paddle comes out with bread.	This can happen, as kneading paddle is detachable. Use a nonmetal utensil to remove it. Caution: Kneading paddle will be hot. Allow bread to cool before removing paddles.
Bread has floured corners.	Sometimes flour in the corners of the bread pan may not have been completely kneaded into dough. Scrape it off the loaf with a knife. Check bread about 10 minutes into kneading cycle. If all flour is not incorporated, use a rubber spatula to remove the flour from the sides of the bread pan so it can be incorporated into the dough.
Can ingredients be halved or doubled?	NO. If there is too little in bread pan, kneading paddle cannot knead well enough. If there is too much, bread rises out of bread pan.
Can fresh milk be used in place of dry milk?	YES. Be sure to decrease same measurement of water to equal liquid substitution. Fresh milk is not recommended when using delay bake timer, because it may spoil while sitting in bread pan.

* Splenda® is a registered trademark of McNeil Nutritionals, LLC.

Applica Consumer Products, Inc. is not affiliated, sponsored or endorsed by McNeil Nutritionals.

Copyright© 2010 Applica Consumer Products, Inc.

Made in People's Republic of China

Printed in People's Republic of China

R12010/2-24-65

NEED HELP?

For service, repair or any questions regarding your appliance, call the appropriate 800 number on cover of this book. Please **DO NOT** return the product to the place of purchase. Also, please **DO NOT** mail product back to manufacturer, nor bring it to a service center. You may also want to consult the website listed on the cover of this manual.

Two-Year Limited Warranty

(Applies only in the United States and Canada)

What does it cover?

- Any defect in material or workmanship provided; however, Applica's liability will not exceed the purchase price of product.

For how long?

- Two years from the date of original purchase with proof of such purchase.

What will we do to help you?

- Provide you with a reasonably similar replacement product that is either new or factory refurbished.

How do you get service?

- Save your receipt as proof of date of sale.
- Visit the online service website at www.prodprotect.com/applica, or call toll-free 1-800-231-9786, for general warranty service.
- If you need parts or accessories, please call 1-800-738-0245.

What does your warranty not cover?

- Damage from commercial use
- Damage from misuse, abuse or neglect
- Products that have been modified in any way
- Products used or serviced outside the country of purchase
- Glass parts and other accessory items that are packed with the unit
- Shipping and handling costs associated with the replacement of the unit
- Consequential or incidental damages (Please note, however, that some states do not allow the exclusion or limitation of consequential or incidental damages, so this limitation may not apply to you.)

How does state law relate to this warranty?

- This warranty gives you specific legal rights. You may also have other rights that vary from state to state or province to province.